



INSTALLATION MANUAL

SOLVA

Intelligent • Integrated • In Control

Integrated Cabinet Battery Energy Storage System



AC261 • DC261 • RT261

This manual specifically covers the installation process.
For a comprehensive overview of other product ranges, visit www.freedomwon.co.za

SOLVA 261 BESS Range

Installation, Commissioning & Maintenance Manual

Document title	SOLVA 261 BESS Range - Installation, Commissioning & Maintenance Manual
Models covered	SOLVA AC261, SOLVA DC261, SOLVA RT261
Document number	FW-SOLVA261-IM
Revision	1
Issue date	2026
Issued by	Freedom Won (Pty) Ltd
Classification	Technical – for qualified installation and service personnel

About this manual

This manual applies to the Freedom Won SOLVA 261 cabinet Battery Energy Storage System (BESS), an all-in-one liquid-cooled cabinet. The larger SOLVA AC418 (418 kWh) cabinet belongs to the wider SOLVA range but is covered by a separate manual.

Contents

1. Preface.....	7
1.1 Overview	7
1.2 About This Manual	7
1.3 Symbol Usage	7
2. Safety Precautions	8
2.1 Personnel Requirements.....	8
2.2 Electrical Safety	8
2.3 Battery Safety	8
2.4 Operation and Maintenance Safety	9
2.5 Storage	9
2.6 Product Disposal	9
3. Product Introduction	10
3.1 The SOLVA 261 Range and Naming	10
3.2 Product Overview	10
3.3 Specifications	11
3.3.1 Common Specifications	11
3.3.2 Model-Specific Specifications	12
3.4 System Architecture	12
3.4.1 SOLVA AC261 - Integrated PCS, AC-coupled	12
3.4.2 SOLVA DC261 - DC-coupled.....	13
3.4.3 SOLVA RT261 - Rectifier, dual conversion	13
3.5 System Control and EMS.....	14
3.6 Electrical Layout	15
3.7 Product Appearance.....	16
3.7.1 Indicators and Buttons	17
3.7.2 Dimensions.....	17
3.7.3 Explosion-Proof Valve.....	18
3.7.4 Fire-Hose Adapter	18
3.8 Internal Components	19
3.8.1 Internal Layout	19
3.8.2 Power Conversion System (PCS) - not fitted to the SOLVA DC261	20
3.8.3 High-Voltage Box (HVB)	25
3.8.4 Battery Module	27
3.8.5 Liquid-Cooling Chiller Unit	29
3.8.6 External Terminals.....	30
3.8.7 UPS Power-Supply Terminal (XT1)	32
3.9 Safety Protection	32
3.9.1 Fire Suppression System (FSS).....	32
3.9.2 Water-Immersion Detection	33
4. Transportation	34

4.1 Precautions	34
4.2 Transportation with Outer Packaging	34
4.2.1 With a Forklift (still in crate)	34
4.3 Handling After Removing from Crate	34
5. Installation.....	36
5.1 Installation Preparation.....	36
5.1.1 Basic Requirements.....	36
5.1.2 Environmental Requirements.....	36
5.1.3 Foundation Preparation	37
5.1.4 Space Requirements.....	37
5.1.5 Cable Preparation.....	40
5.2 On-Site Installation	40
5.2.1 Removal of Packaging	40
5.2.2 Cabinet Foundation	41
5.2.3 Accessories and Cable Connection	43
5.2.4 DC Connections Specific to the DC261	46
5.2.5 Sealing of Inlet Holes	48
5.2.6 On-Grid Parallel Connection (SOLVA AC261)	49
5.2.7 Off-Grid Application (SOLVA AC261)	49
5.2.8 Installation Checklist	49
6. Power On and Off	50
6.1 Power-On.....	50
6.2 Charging and Discharging.....	50
6.3 Power-Off	50
7. Maintenance	51
7.1 Emergency Faults	51
7.1.1 Fire	51
7.1.2 Water Flooding.....	51
7.2 System Maintenance	51
7.2.1 Maintenance Methods	51
7.2.2 Maintenance Intervals.....	51
7.3 Component Maintenance.....	52
8. Warranty.....	53
9. Support and Contact.....	53
Appendix A – Tightening Torques	53
Appendix B – Detailed Single-Line Diagrams	54
B.1 SOLVA AC261 – Detailed Single-Line Diagram	55
B.2 SOLVA DC261 – Detailed Single-Line Diagram	56
B.3 SOLVA RT261 – Detailed Single-Line Diagram.....	57

List of Figures

Figure 3-1 SOLVA Naming Convention	10
Figure 3-2 SOLVA 261 Cabinet	11
Figure 3-3 SOLVA AC261 System Architecture Example (Overview)	12
Figure 3-4 SOLVA DC261 System Architecture Example (Overview)	13
Figure 3-5 SOLVA RT261 System Architecture Example (Overview)	13
Figure 3-6 System Communication Architecture	14
Figure 3-7 Electrical Diagram	15
Figure 3-8 Cabinet Appearance and Structure	16
Figure 3-9 Cabinet Dimensions	17
Figure 3-10 Explosion-Proof Valve	18
Figure 3-11 External Fire-Fighting Water Attachment Fitting	18
Figure 3-12 Internal Layout of the Cabinet	19
Figure 3-13 125 kW PCS Module	20
Figure 3-14 125 kW PCS Front and Rear Views Showing Terminals and Ports (Described in the Table Below)	21
Figure 3-15 Electrical Circuit Diagram of the PCS Module Internals	22
Figure 3-16 Ports and Features on the Front Face of the PCS	23
Figure 3-17 Ports and Features on the Rear of the PCS	24
Figure 3-18 High-Voltage Box Ports and Features	26
Figure 3-19 Battery Pack with Dimensions	27
Figure 3-20 Battery Pack Front and Rear Views Showing Plugs, Ports and Features	28
Figure 3-21 Liquid-Cooling Chiller Unit	29
Figure 3-22 Liquid-Cooling Chiller Unit Ports and Features	30
Figure 3-23 COM1 Communication Terminal	30
Figure 3-24 Parallel-Connection RJ45 Port	31
Figure 3-25 UPS Power-Supply Terminal	32
Figure 3-26 Cabinet Aerosol Generator	33
Figure 4-1 Schematic Diagram of Handling with a Forklift	34
Figure 4-2 Handling with a Forklift (Without Bottom Wooden Pallet)	35
Figure 4-3 Handling with a Crane	35
Figure 5-1 Front and Rear Space Requirements for One Cabinet	37
Figure 5-2 Suggested Layout with Six Cabinets	38
Figure 5-3 Suggested Layout with Twelve Cabinets – Main Doors Facing Inwards	38
Figure 5-4 Suggested Layout with Twelve Cabinets – All Main Doors Facing Forwards	39
Figure 5-5 Suggested Layout with Twelve Cabinets – Main Doors Facing Outwards	39
Figure 5-6 Cabinet Mounted on Steel Channel	41
Figure 5-7 Cabinet Mounted on Concrete Plinths	42
Figure 5-8 Method for Multiple Cabinets Mounted on Steel Channel – Frame Example	42
Figure 5-9 On-Site Wiring and Installation Actions	43
Figure 5-10 MSD Installation	44
Figure 5-11 Communication Terminals on the HVB	44
Figure 5-12 COM1 Plug for Connections to the STS or POC Cabinet	44
Figure 5-13 PARA Communications Ports	45
Figure 5-14 Grounding-Plate Connection	46
Figure 5-15 Cabinet with Inverter	47
Figure 5-16 Diagram of DC cable connections	48
Figure 5-17 On-Grid Parallel Connection	49

List of Tables

Table 3-1 Model Categories	10
Table 3-2 Common Specifications	11
Table 3-3 Model-Specific Specifications.....	12
Table 3-4 External Features as per Labels in Figure 3-8.....	16
Table 3-5 Indicators and Buttons on the Cabinet.....	17
Table 3-6 PCS Specific Parameters and Specifications.....	20
Table 3-7 Labelling to Figure 3-14.....	21
Table 3-8 Descriptions of Features Shown in Figure 3-16	23
Table 3-9 PCS Rear Ports and Features.....	24
Table 3-10 Description of Features Shown in Figure 3-17.....	25
Table 3-11 HVB Main Switches and Functions	25
Table 3-12 Features Labelled on Figure 3-18.....	26
Table 3-13 Battery Pack Parameters	27
Table 3-14 Labels to Figure 3-20	28
Table 3-15 Chiller Specifications	29
Table 3-16 Labels to Figure 3-22	30
Table 3-17 Pin Definition for Figure 3-23 Plug.....	31
Table 3-18 Pinout for RJ45 Plug in Figure 3-24	31
Table 3-19 Terminal Descriptions for Figure 3-25	32
Table 3-20 Cabinet Aerosol Generator Specifications	33
Table 5-1 Minimum Recommended Distances from Other Buildings	36
Table 5-2 Recommended Cable and Terminal Specifications	40
Table 5-3 Pinout for COM1 Plug.....	45
Table 5-4 DC cable connections.....	46
Table 5-5 Features Labelled on Figure above	47
Table 5-6 DC cable connections	48
Table 7-1 Maintenance Intervals	52
Table A-1 Recommended Tightening Torques by Bolt Size	53

1. Preface

1.1 Overview

This manual describes the installation, electrical connection, commissioning and maintenance of the Freedom Won SOLVA 261 energy storage system. Read it carefully before installing or operating the system so that you understand the safety requirements and become familiar with the product's functions and features.

This manual applies to all three variants of the SOLVA 261 battery cabinet. Any differences between the variants are noted at the relevant point in the text; where no note is given, the information applies to all three.

1.2 About This Manual

Read this manual in full and make sure you understand the equipment before installing, operating or maintaining it. The content is updated periodically, and minor differences may exist between the manual and the delivered product; always refer to the physical product you have purchased and obtain the latest revision from Freedom Won or an authorised channel.

1.3 Symbol Usage

The following signal words are used throughout this manual to highlight information that protects personal and property safety. Only suitably trained and qualified personnel may carry out the procedures described.

Signal word	Meaning
DANGER	An imminently hazardous situation that, if not avoided, will result in death or serious injury.
WARNING	A hazardous situation that, if not avoided, could result in death or serious injury.
CAUTION	A hazardous situation that, if not avoided, may result in minor or moderate injury, or property damage.
ATTENTION	A potential risk that, if not avoided, may lead to equipment malfunction or property damage.

The hazard labels fitted to the cabinet are shown below and must always be observed.

Symbol	Label	Meaning
	High voltage	Hazardous voltage is present inside the unit. Contact may cause a fatal electric shock.
	Hot surface	The surface temperature may exceed the safe limit for human contact. Do not touch.
	Protective Earth (PE)	Protective-earth terminal. It must be securely bonded to site earth for operator safety.
	Battery hazard	Risk of battery fire, explosion or related hazards. Observe all battery safety precautions.
	Arc flash	Risk of arc-flash explosion and burns. Use appropriate PPE and procedures.

2. Safety Precautions

Danger - lethal voltage

Lethal DC and AC voltages are present inside the cabinet during operation and for a period after shutdown. After disconnecting the supply, the battery does not de-energise immediately. Allow at least 10 minutes and verify the absence of voltage with a meter before any contact.

2.1 Personnel Requirements

Lifting, transport, installation, wiring, operation and maintenance of the system must be carried out only by professional electrical technicians working in accordance with local regulations. As a minimum, such personnel must:

- Have a sound understanding of electronics, electrical wiring and mechanics, and be able to read electrical and mechanical schematics;
- Be familiar with the construction and operating principles of the energy storage system and its upstream and downstream equipment;
- Have completed professional training in the installation and commissioning of electrical systems;
- Be able to manage emergencies and unexpected situations during installation or commissioning;
- Be familiar with the standards and regulations applicable in the country or region of the installation.

2.2 Electrical Safety

- Touching points or terminals connected to the grid or to internal equipment can cause electric shock. Both the battery and grid sides can be live.
- Always confirm the absence of voltage with a standard voltmeter before making contact and observe the warning labels on the product.
- Damaged internal components may cause electric shock or fire. Comply with all safety precautions in this and related documentation.
- After the supply is disconnected the battery does not power off immediately - wait at least 10 minutes before opening the cabinet.
- Install prominent warning signs and safety barriers around the system to prevent unauthorised access and accidental energisation.

2.3 Battery Safety

Observe the high-voltage, hot-surface and protective-earth labels on the battery and cabinet. To ensure safe operation, technical personnel must follow the safety protocols in this manual. Freedom Won accepts no liability for malfunction, component failure, injury or property damage arising from, among other things:

- Loss or permanent impairment of capacity caused by delayed charging or repeated deep discharge;
- Damage or leakage caused by incorrect use, neglect of operating procedures or unsuitable charging/discharging equipment;
- Incorrect configuration of battery operating parameters, or unauthorised changes such as self-installed additional loads;
- Inadequate maintenance, continued use after warranty expiry, or use of faulty or physically distorted batteries;
- Mixing the supplied batteries with batteries of other brands or capacity ratings;
- Improper storage or installation near flammable or explosive materials, or operation outside the rated conditions.

2.4 Operation and Maintenance Safety

- Wear appropriate personal protective equipment for all maintenance, inspection and related tasks - safety goggles, helmet, insulated footwear, gloves and protective clothing.
- The battery unit contains no user-serviceable parts. Removal, replacement or handling of the battery may be performed only by Freedom Won-authorized personnel.
- Do not perform any maintenance procedure not described in this manual; for repairs, contact Freedom Won after-sales service.
- Do not disassemble or burn the battery - this poses a significant fire hazard.
- Do not apply substances to components, and do not clean the equipment with solvents or harsh chemicals.

2.5 Storage

If the system is not installed soon after delivery, store it with its transport packaging and desiccant retained, in a ventilated, dry, clean indoor environment, observing the following:

- Keep the cabinet state of charge between 30% and 50% during storage; avoid long-term storage below 15% SOC and switch off power-consuming equipment if the cabinet will be idle.
- The storage floor must be flat and able to bear the cabinet weight; the environment must be free of corrosive, combustible or explosive gasses or materials.
- Short term storage temperature -20°C to 55°C; relative humidity 0-95% non-condensing. Keep the cabinet at least 2 m from heat sources, elevate the package at least 20 cm off the floor and at least 50 cm from walls, windows or air intakes. Long term (>3 months) storage temperature range required is 15°C to 25°C.
- Inspect at least weekly for packaging damage or rodent activity and remedy or replace damaged packaging immediately.

2.6 Product Disposal

At end of life the battery system must not be disposed of as ordinary waste. Contact an authorised recycling agency for proper disposal.

3. Product Introduction

3.1 The SOLVA 261 Range and Naming

Every SOLVA model follows the naming convention [Category] + [Capacity]. The category prefix identifies the power-conversion architecture, and the numeric suffix identifies the energy capacity in kWh.




Figure 3-1 SOLVA Naming Convention

Table 3-1 Model Categories

Category	Meaning	Application
AC	Integrated PCS (bidirectional inverter)	AC-coupled storage connected directly to a 400 V AC bus
DC	DC-coupled battery cabinet	Connected on the DC bus of an external hybrid or central inverter
RT	Rectifier (dual conversion)	Grid-fed DC charging with an isolated load bus via an external inverter

All three 261 models share the same 261 kWh lithium iron phosphate (LiFePO₄) battery platform, liquid thermal management, IP55 outdoor enclosure and integrated safety systems. They differ only in how energy is converted and connected to the site:

- **SOLVA AC261** - integrated 125 kW PCS architecture with AC-bus parallel capability, optional external Static Transfer Switch (STS) and simplified single-cabinet deployment.
- **SOLVA DC261** - flexible DC-coupled architecture for use with external hybrid or central inverters; up to 12 cabinets in DC parallel, scaling on the inverter AC side.
- **SOLVA RT261** - dual-conversion architecture with an integrated 125 kW rectifier for independent grid-based charging and an isolated load bus that protects critical loads from poor grid quality.

3.2 Product Overview

The SOLVA 261 is an all-in-one, liquid-cooled commercial and industrial energy storage cabinet. A single enclosure integrates the LiFePO₄ battery packs, the High-Voltage Box (HVB), the Power Conversion System (PCS) (except for the DC261), the Fire Suppression System (FSS), the liquid-cooling chiller unit and the cabinet control and monitoring electronics.

The cabinet is energy-efficient and compact, with high energy density, broad environmental adaptability, rapid on-site installation, grid compatibility and straightforward capacity expansion.



Figure 3-2 SOLVA 261 Cabinet

3.3 Specifications

3.3.1 Common Specifications

The table below provides the specifications that are common across the three SOLVA models.

Table 3-2 Common Specifications

Parameter	Value
Cell type / capacity	Lithium iron phosphate (LiFePO ₄), 314 Ah
Module configuration	52.2 kWh, 1P52S
Pack configuration	261 kWh, 1P260S (5 Modules per pack)
Rated DC voltage / range	832 V / 728–936 V
Max. charge / discharge rate	0.5 P
Rated power	125 kW
Cycle life	≥ 8 000 cycles
Communication	Modbus TCP/IP, RS485, CAN
Fire suppression	Pack-level and cabinet-level aerosol
Cooling	Active liquid cooling
Ingress / corrosion protection	IP55 / C4 (C5 optional)
Operating temperature	–25 °C to 55 °C (derating above 45 °C)
Humidity / altitude	5–95% RH non-condensing / 4000 m (derating above 2000 m)
Noise	≤ 75 dB
Standards & Certifications	UN38.3, (Optional version with: IEC 62477-1, IEC 61000, IEC 62619, IEC 63056)

3.3.2 Model-Specific Specifications

The table below provides the specifications that differ across the three SOLVA models.

Table 3-3 Model-Specific Specifications

Parameter	AC261	DC261	RT261
Architecture	Integrated PCS (AC-coupled)	DC-coupled	Rectifier (dual conversion)
Power conversion	125 kW bidirectional PCS	DC busbars (no internal converter)	125 kW rectifier + DC busbars
AC connection	400 V output, 3P+N+PE	-	400 V input, 3P+N+PE
DC connection	-	DC busbars, 125 kW	DC busbars, to inverter
External inverter comms	-	CAN bus	CAN bus
Parallel capability	24 on-grid / 6 off-grid (AC bus)	Up to 12 (DC parallel)	Up to 12 (DC parallel)
Weight	≈ 2.7 t	≈ 2.5 t	≈ 2.7 t
Grid Compliance	NRS-097, AS/NZS 4777.2	-	NRS-097, AS/NZS 4777.2

3.4 System Architecture

The three architectures are summarised below; full-size detailed single-line diagrams are provided in Appendix B.

3.4.1 SOLVA AC261 – Integrated PCS, AC-coupled




Figure 3-3 SOLVA AC261 System Architecture Example (Overview)

3.4.2 SOLVA DC261 - DC-coupled




Figure 3-4 SOLVA DC261 System Architecture Example (Overview)

3.4.3 SOLVA RT261 - Rectifier, dual conversion




Figure 3-5 SOLVA RT261 System Architecture Example (Overview)

3.5 System Control and EMS

The SOLVA 261 uses a three-level internal communication architecture:

- **Level I - BMU (battery slave units):** acquire pack voltage, temperature and related signals and perform cell balancing.
- **Level II - BCU (battery master controller):** aggregates and processes the BMU signals, controls charge/discharge, enforces protection thresholds and executes the thermal-management strategy.
- **Level III - Cabinet Monitoring System (CMS) / Cabinet EMS:** the control core of the cabinet; through an I/O module it acquires, monitors and controls the BMS, PCS, HVB and FSS status and presents the cabinet to the site EMS.




Figure 3-6 System Communication Architecture

Multiple CMS can communicate with each other, with one acting as the master to connect to a central inverter or STS (where applicable).

These EMS control levels sit above the CMS:

- **Microgrid EMS / Site EMS:** Coordinates control of the site and performs Time-of-Use (TOU) scheduling, energy arbitrage, etc. Where applicable, it maintains communication and/or control of the BESS (via the CMS), STS, ATS, generator (starter signal), hybrid inverters, central inverters,

meters, switchgear, etc. Microgrid EMS can be integrated into the STS or located near the grid connection point.

- **Cloud EMS:** Provides remote monitoring, logging and parameter updates to the site EMS. Can be used to monitor multiple sites in the portfolio.
- **Hybrid Inverter EMS:** When used with the SOLVA DC261, hybrid inverters can perform system-level control using their built-in EMS. This will enable TOU scheduling, energy arbitrage, remote monitoring, etc.

3.6 Electrical Layout

The cabinet is a self-contained battery system with ancillary systems integrated to allow for standalone operation and integration with external equipment such as a Static Transfer Switch (STS) and external microgrid EMS. The schematic below illustrates the internal components. Note that the PCS is excluded from the SOLVA DC261 and replaced with busbars for connection to the DC ports of an external inverter and/or to other DC261 cabinets or supplied with plug in DC connectors (depending on requirements).




Figure 3-7 Electrical Diagram

3.7 Product Appearance

The cabinet's external features are listed below.

Table 3-4 External Features as per Labels in Figure 3-8

Item	Component	Function
A	Lifting rings (4)	For lifting the cabinet; shipped inside the cabinet for transport.
B	Audible & visual alarm	Indicates a potential fire alarm.
C	Indicator lights	White = powered on; green = running; red = fault.
D	Emergency-stop button	Press to shut the system down immediately.
E	Front door locks (2)	Upper section: battery compartment; lower section: electrical components.
F	Explosion-proof valve	Relieves over-pressure inside the cabinet. <i>Note: Some models may include two servo actuated valves, one for inlet and one for outlet to disperse flammable gasses on detection by the optional gas detector.</i>
G	Fire-hose adapter	Connection point for a fire-water hydrant.
H	Rear door lock	Access for maintenance of electrical components.
I	Grounding copper plate	Cabinet protective-earth connection.




Figure 3-8 Cabinet Appearance and Structure

3.7.1 Indicators and Buttons

The following table provides a description of the visual and audible interfaces for the operator standing in front of the cabinet.

Table 3-5 Indicators and Buttons on the Cabinet

Indicator / button	State	Description
Audible & visual alarm	On / Off	On when a smoke or temperature sensor is triggered.
White – POWER	On / Off	On when both QF2 and QF4 are closed.
Green – RUN	On / Off	On when charging ≥ 5 kW or discharging ≥ 3 kW; off in standby.
Red – FAULT	On / Off	On when a fault occurs.
Emergency stop	Pressed	Immediately cuts the EMS, BMS and DC power; the system must be restarted after release.

3.7.2 Dimensions

Cabinet dimensions (W × D × H): 1050 × 1350 × 2400 mm; weight approximately 2700 kg. Cable entry and exit are at the bottom of the cabinet.

Note: Dimensions may vary between models – confirm final dimensions with order placement.




Figure 3-9 Cabinet Dimensions

3.7.3 Explosion-Proof Valve

The explosion-proof valve protects the cabinet against internal over-pressure. When the internal pressure reaches the opening pressure, the relief port opens and the opening area increases with pressure, keeping the internal pressure at a safe level. Rating: IP66; maximum relief area > 5836 mm²; activation pressure 5–10 kPa; working temperature -20 to 80 °C. Refer to Figure 3-10 below showing a rendered image of both sides of the valve device.




Figure 3-10 Explosion-Proof Valve

3.7.4 Fire-Hose Adapter

The fire-hose adapter is fitted with a standard DN65 coupling forged from aluminium-magnesium alloy with an anodised surface and oil-resistant rubber seal, rated for a working pressure up to 2.5 MPa, allowing a fire-service hose to be connected to the cabinet. The figure below provides the dimensions of the fitting for local fire equipment interface planning.





Figure 3-11 External Fire-Fighting Water Attachment Fitting

3.8 Internal Components

3.8.1 Internal Layout

The cabinet houses the battery packs, High-Voltage Box, Power Conversion System (excluded from the DC261 version), liquid-cooling chiller unit and external terminals, together with the smoke, temperature and immersion sensors and the AC power port.

Internal Equipment Layout Labels



No.	Item
1	Smoke Sensor
2	Temperature Sensor
3	Battery Packs
4	High Voltage Box
5	External Terminals
6	AC Power Port
7	Power Conversion System (PCS)
8	Liquid-cooling Chiller Unit
9	Immersion Sensor

Figure 3-12 Internal Layout of the Cabinet

3.8.2 Power Conversion System (PCS) - not fitted to the SOLVA DC261

The PCS in the SOLVA AC261 and RT261 provides bidirectional conversion: it converts DC to AC to feed the grid or AC loads and rectifies AC to DC to charge the battery.

Table 3-6 PCS Specific Parameters and Specifications

PCS parameter	Value
Rated power / rated output current	125 kW / 137.5 A
AC wiring / isolation	3L+N+PE or 3L+PE / transformerless
Rated AC voltage / range	400 V $\pm$ 15%
Overload capacity	110% long-term at ambient $\leq$ 35 °C
Max. efficiency	98.5%
Protection	Short-circuit, AC phase-sequence, anti-islanding, DC/AC over-voltage, reverse-polarity, over-heating, LVRT, comms-fault
Cooling / ingress	Air cooling / IP20
Communication	RS485 & Modbus-RTU (EMS); CAN (BMS)
Dimensions / weight	520 $\times$ 785 $\times$ 232 mm / 69 kg

The PCS is a rack mounted form factor – an image of the module is provided below.



Figure 3-13 125 kW PCS Module




Figure 3-14 125 kW PCS Front and Rear Views Showing Terminals and Ports (Described in the Table Below)

Table 3-7 Labelling to Figure 3-14

No.	Name	Description
1	Indicator light	Steady-on in green when power is on; Fast flash in green at 0.5s intervals when standby; Slow flash at 1s intervals when power is off with no fault. Continuous in red when a fault occurs.
2	Communication terminals area (Front)	Please refer to Fig 3-16 for details
3	220V power input terminal	220Vac input (internal use only)
4	AC interface	For AC cable connection
5	DC interface	For DC cable connection
6	Communication terminals area (Back)	Please refer to Fig 3-17 for details
7	PE	For grounding connection

The PCS communication terminals (front and back panels) provide the Ethernet/Modbus-TCP EMS interface, RS485 and CAN to the BMS, the emergency-stop and DRM inputs, BMS-fault and off-grid start inputs, status outputs, and the Para1/Para2 ports used for PCS-parallel operation (Where applicable) or connection to an STS. CAN matching resistors are engaged by the corresponding DIP switches.

Refer to below diagram for details about the internal circuits of the PCS module.




Figure 3-15 Electrical Circuit Diagram of the PCS Module Internals

The ports and features on the front of the PCS are detailed below.




Figure 3-16 Ports and Features on the Front Face of the PCS

Table 3-8 Descriptions of Features Shown in Figure 3-16

Terminal Name	Function
BT	Bluetooth indicator light: The blue light comes on when the Bluetooth connection is successful.
USB	Reserved USB port for software/firmware updates/configuration file uploads.
ADDR	Module address setting DIP switch (binary), with the 4th bit being the least significant bit (counting from right to left).
120Ω	"120Ω" indicates a 4-bit binary DIP switch. 1 – ARM_CAN1: Reserved CAN communication matching resistor, flip up to engage the 120Ω matching resistor. 2 – ARM_CAN2: Reserved CAN communication matching resistor, flip up to engage the 120Ω matching resistor. 3 – SYNC_CAN1: CAN signal matching resistor in the para, for PCS parallel communication, flip up to engage the 120Ω matching resistor. 4 – DSP_CAN2: CAN signal matching resistor in the Phoenix terminal, flip up to engage the 120Ω matching resistor.
ETH	Ethernet port, supports the Modbus TCP protocol, can be connected to EMS or switch.
COMM3	Reserved for future use
TEST	For Freedom Won use only

The ports and features of the rear of the PCS are detailed below.

Table 3-9 PCS Rear Ports and Features




Terminal	Pin	Function
 Power Supply Terminal	24V	Reserved, 24V DC output interface, supply power <20W and is intended solely for use with DI/DO
	GND	
	B-	Reserved, current sampling interface
	B+	
	A-	Reserved, current sampling interface
	A+	
Terminal	Pin	Function
 External Comm Terminal	RS485	RS485 communication interface
	EP0	Emergency stop signal input interface, default normally close.
	DRM0	DRM monitoring interface, default normally open.
	DI1	BMS fault signal, default normally close
	DI2	Off-grid manual start signal, default NO
	CAN	CAN communication with BMS
	DI3	External DI interface
	DO1	24V power supply fault status signal
	DO2	24V power supply operating status signal
	DO3	24V power supply fan control signal
 Parallel Connection Terminal	PARA1 & PARA2	PCS parallel connection or PCS connect with STS

Figure 3-17 Ports and Features on the Rear of the PCS

Table 3-10 Description of Features Shown in Figure 3-17

Pin	Pin Definition	Description
1	CAN1_L	CAN communication parallel signal
2	CAN1_H	
3	INV_SYNC	Internal AC frequency synchronization signal
4	GND	Common signal terminal
5	CARRIER_SYNC	Internal carrier synchronization signal
6	GND	Common signal terminal
7	/	Reserved
8	/	Reserved

3.8.3 High-Voltage Box (HVB)

The High-Voltage Box manages the high-voltage DC circuit and houses the Cabinet Management System (CMS) together with the main breakers and fuses, providing control, protection and communication for the cabinet. Its main switches are:

Table 3-11 HVB Main Switches and Functions

Switch	Function
QF1	Main switch - connects the main positive/negative battery contactors.
QF2	Auxiliary-power main breaker - activates the 220 V auxiliary supply.
QF3	Chiller-unit breaker - powers the liquid-cooling unit (self-check and start).
QF4	Auxiliary-devices breaker - powers the 220/24 V supply for the BMS, EMS, fans and sensors.

The HVB also provides the battery and PCS DC connectors (B+/B-, P+/P-), a 230 V AC service socket, RUN/FAULT indicators, the EMS debug and external-communication ports, and the BMS/PCS, I/O and internal-device communication ports. The four internal communication ports are factory-connected and require no on-site wiring.




Figure 3-18 High-Voltage Box Ports and Features

Table 3-12 Features Labelled on Figure 3-18

No.	Symbol	Name	Description
1	B+	Battery positive connector	Positive pole connection between PACK and HVB
2	B-	Battery negative connector	Negative pole connection between PACK and HVB
3	QF1	HVB Main Switch	Main switch of HVB
4	QF2	Auxiliary power main circuit breaker	Auxiliary power control inside the cabinet
5	QF3	Chiller unit power circuit breaker	Power supply control of chiller unit
6	QF4	Auxiliary devices circuit breaker	Power supply for BMS, EMS, fans, sensor and other devices
7	CZ	230V AC output socket	230V AC output socket for installation or maintenance use
8	RUN	Operation indicator light	Indicate the normal operating status of the high-voltage box
9	FAULT	Fault indicator light	Indicate the shutdown status of the high-voltage box due to malfunction
10	COM1	EMS debug port	For EMS debugging or testing
11	COM2	External communication port	For connecting gateway or third-party EMS
12	GAM	BMS & PCS communication port	For BMS and PCS communication
13	GBM	I/O signal communication port	For HVB internal I/O module signal communication
14	GCM	Internal device communication port	For the communication between HVB and other internal devices
15	JX1	HVB power supply port	For HVB power supply
16	P+	PCS positive connector	Positive pole connection between PCS and HVB
17	P-	PCS negative connector	Negative pole connection between PCS and HVB

The I/O plugs are prewired and thus no on-site wiring is required. Detailed pinouts are available from Freedom Won on request should detailed inspection be required of the wiring system.

3.8.4 Battery Module

The cabinet uses liquid-cooled LiFePO_4 battery modules with 314 Ah cells in a 1P52S configuration. Liquid cooling holds the cell-to-cell temperature difference within 3°C , improving efficiency and service life. There are 5 modules in series in each 261kWh pack.

Table 3-13 Battery Pack Parameters

Battery pack parameter	Value
Cell Chemistry	LiFePO_4
Rated Capacity [Ah]	314
Grouping	1P52S
Rated Energy [kWh]	52.25
Rated voltage / range	166.4 V / 145.6–187.2 V
Rated charge / discharge rate	0.5P
Cycle life	$\geq 8\,000$ cycles at 75%
Operating temperature	-20 to 50°C (discharge) / 0 to 55°C (charge)
Ingress Protection	IP65
Dimensions (H×W×D) [mm]	238 × 812 × 1132
Weight [kg]	350



Figure 3-19 Battery Pack with Dimensions




Figure 3-20 Battery Pack Front and Rear Views Showing Plugs, Ports and Features

Table 3-14 Labels to Figure 3-20

No.	Item	No.	Item
1	Power-in connector	6	BMS Communication port
2	Power-out connector	7	Liquid cooling inlet
3	MSD	8	Liquid cooling outlet
4	Warning signs	9	Pressure relief valve
5	Pack nameplate		

The BMS connection port is prewired and thus no on-site wiring is required. Detailed pinouts are available from Freedom Won on request should detailed inspection be required of the wiring system.

3.8.5 Liquid-Cooling Chiller Unit

A drawer-type 5 kW chiller provides active thermal management. Its integrated chassis is easy to install and maintain and supports CAN communication, power-off memory, self-start and intelligent cooling/heating. A variable-frequency compressor and water pump regulate the refrigeration and coolant circuits for efficient operation, giving a small temperature difference and rapid cooling that extends battery life. Coolant that has been chilled by the chiller is pumped through a heat exchanger base upon which the cells in each module are fixed. The chilling of this base extracts heat from the bottom of the cells, thus regulating their temperature.

Table 3-15 Chiller Specifications

Chiller parameter	Value
Operating Voltage	230 V $\pm$ 15%, 50/60 Hz $\pm$ 3 Hz
Operating Temperature / Humidity	-30 to +55 °C / 5-95% RH
Max. Flow / IP	50 L/min / IP55
Inlet / Outlet Coolant Temperature	-30 to 55 °C / 5 to 40 °C
Dimensions (W $\times$ D $\times$ H) [mm]	245 x 700 x 900 (without flange)



Figure 3-21 Liquid-Cooling Chiller Unit




Figure 3-22 Liquid-Cooling Chiller Unit Ports and Features

Table 3-16 Labels to Figure 3-22

No.	Item	No.	Item
1	Coolant Inlet	5	Debug Interface
2	Coolant filling & drain Port	6	Power Interface
3	Coolant Output	7	Air Output
4	COM Interface	8	Air Input

3.8.6 External Terminals

Three external terminals are provided: the COM1 communication terminal (on-site meter connection, communication with a Point-of-Connection (POC) cabinet and on-site debugging); the parallel-connection terminal (two RJ45 ports for off-grid parallel operation of multiple cabinets); and the UPS power-supply terminal (XT1), a reserved interface for connecting an external UPS (pins 3-5 and 4-6 are factory-linked and are removed when a UPS is connected).




Figure 3-23 COM1 Communication Terminal

Table 3-17 Pin Definition for Figure 3-23 Plug

Pin No.	Definition	Pin No.	Definition
1	Breaker status DI signal	9	BMS debugging CANL
2	Breaker status COM signal	10	PCS debugging RS485A1
3	Breaker trip DO+ control	11	PCS debugging RS485B1
4	Breaker trip DO- control	12	RS485A2(Reserved)
5	/	13	RS485B2(Reserved)
6	On-site Meter Comm. RS485A	14	/
7	On-site Meter Comm. RS485B	15	/
8	BMS debugging CANH	16	/

The parallel connection terminal employs two RJ45 ports for communication when multiple ESS cabinets need operate in off-grid parallel application.




Figure 3-24 Parallel-Connection RJ45 Port

Table 3-18 Pinout for RJ45 Plug in Figure 3-24

Pin	Pin Definition	Description
1	CAN1_LL	CAN communication parallel signal
2	CAN1_H	
3	INV_SYNC	Internal AC frequency synchronization signal
4	GND	Common signal terminal
5	CARRIER_SYNC	Internal carrier synchronization signal
6	GND	Common signal terminal
7	/	Reserved
8	/	Reserved

3.8.7 UPS Power-Supply Terminal (XT1)

UPS Power Supply Terminal is used to supply UPS power to the SOLVA for the small loads on systems that may operate when there is no grid power present.

Before factory delivery, Pin 3 is short-circuited with Pin 5, and Pin 4 is short-circuited with Pin 6. When an external UPS is to be connected, simply remove the link between Pin 3 and Pin 4 and connect them to the L and N terminals of the UPS respectively.




Figure 3-25 UPS Power-Supply Terminal

Table 3-19 Terminal Descriptions for Figure 3-25

Pin	Pin Definition	Description
1	/	/
2	/	/
3	PCS Power: L	PCS L phase output
4	PCS Power: N	PCS N phase output
5	UPS Power: L	Connect to external UPS L
6	UPS Power: N	Connect to external UPS N

3.9 Safety Protection

The cabinet carries detectors for smoke, temperature and water immersion, with pack-level aerosol and two cabinet-level aerosol units, allowing hazards to be detected in real time and fire incidents to be prevented.

3.9.1 Fire Suppression System (FSS)

- **Module-level:** each pack has an internal module-level aerosol device that detects fire and extinguishes it automatically without a power supply; it activates when fire or heat reaching 185 °C is detected.
- **Cabinet-level:** an aerosol-based system that activates when both the smoke and temperature sensors are triggered; the explosion-proof valve relieves pressure, and the FSS notifies all related personnel and systems.

The aerosol generators act through a redox reaction that releases a chemical coolant to extinguish the fire. The smoke detector uses forward light-scattering (alarm threshold 0.15 dB/m) and the heat detector trips above 65 °C.

Details of the cabinet aerosol generator are provided below.



Figure 3-26 Cabinet Aerosol Generator

Table 3-20 Cabinet Aerosol Generator Specifications

Item	Parameter
Net Weight per Unit	1145g ± 30g
Operating Temperature Range [°C]	-30 - +7
Dimensions [mm]	247 x 67 x 66
Operating Humidity	≤95% RH
Activation Method	Electrical/Thermal
Discharge Time [sec]	≤15
Electrical Activation Current [mA]	≥700
Protection Volume	3m ³
Nozzle Heat Distance	Temperature ≤200°C at 400mm from nozzle
Surface Temperature of Shell [°C]	≤200
Oxidizer Name and Content	Strontium nitrate, potassium nitrate 50% ~ 58%

3.9.2 Water-Immersion Detection

A solid-state water sensor at floor level detects the presence of water (sensing level 3 ±1 mm) and switches its output to alarm, allowing the system to respond to flooding. Supply 24VDC; operating temperature -10 to 60°C.

4. Transportation

4.1 Precautions

Caution - transport

Do not disassemble the cabinet during transport or installation. Never tilt the cabinet by more than 5° – because the centre of gravity is not the mechanical centre, excessive tilt can overturn it, causing injury or damage. Always observe the centre-of-gravity marking.

- Transport the cabinet strictly as described in this chapter; unauthorised modification voids the warranty.
- Avoid mechanical shock such as violent shaking or sudden lifting/lowering, and avoid transporting in rain (take rain-proofing measures if unavoidable).
- Only licensed, authorised personnel may handle the cabinet, using equipment of sufficient load-bearing capacity.

4.2 Transportation with Outer Packaging

Wherever possible, transport the cabinet in its packaging, observing the package symbols (right-side-up, handle with care, keep dry, no rolling, no stacking, centre of gravity, hazardous goods class 9). Ensure handling equipment has adequate capacity and arrange support or lifting points correctly.

4.2.1 With a Forklift (still in crate)

Place the centre of gravity between the forks; the forks must be at least 1.6 m long. Conduct a trial lift, move slowly and smoothly, and set the cabinet down only on hard, level ground. Because the packaging may block the driver's view, use a banksman to assist. Follow all forklift safety procedures.




Figure 4-1 Schematic Diagram of Handling with a Forklift

Lifting with a crane (sling) while the battery is still inside the crate is not recommended.

4.3 Handling After Removing from Crate

Near the final position the unpacked cabinet may be moved by forklift or crane. Lay cables before positioning the cabinet, as routing becomes difficult once it is seated.

- Forklift: with the pallet, keep the centre of gravity between the forks; without the pallet, place the forks directly in the base fork grooves (remove the base baffle first). Move slowly on hard, level ground.




Figure 4-2 Handling with a Forklift (Without Bottom Wooden Pallet)

- Crane: install the lifting rings (shipped inside the cabinet) at the four top corners first. Keep the hook centred over the cabinet, conduct a trial lift, keep the rope angle greater than 60° , and never lift tilted.



Figure 4-3 Handling with a Crane

5. Installation

5.1 Installation Preparation

5.1.1 Basic Requirements

Follow all standards and requirements applicable at the installation site and use only equipment specified by Freedom Won. The IP55 cabinet is intended for industrial environments; ensure the installation environment meets the following:

- The ground is dry, flat, free of standing water and strong enough to bear the cabinet weight, without movement;
- Ambient temperature -20 °C to 55 °C and relative humidity 0-95% non-condensing;
- Sufficient space in front of and behind the cabinet for ventilation, heat dissipation, maintenance and escape;
- Cabinet grounding resistance below 4 Ω , indicators and screen accessible, and no flammable gases or combustible materials nearby;
- A clean installation environment.

5.1.2 Environmental Requirements

Permitted locations: outdoors, inside a dedicated energy-storage building, or inside buildings equipped with fire-prevention and ventilation measures. The system must not be installed in residential units, lift shafts, stairwells, refuge floors or other critical passages and evacuation routes. Reserve space for future expansion and parallel connection.

Fire safety: keep the site clear of vegetation within 3 m, install fire extinguishers per local codes and reserve a connection port for a water-based fire-suppression system. Observe local safety-distance requirements between the equipment and buildings; where the distance cannot be met, build a fire-rated wall. Consult your fire engineer to ensure compliance with SANS 10400-Part T, NFPA 855, or any other applicable fire code.

Table 5-1 Minimum Recommended Distances from Other Buildings

Building classification	Minimum safe distance
Residential housing	≥ 12 m
Schools, hospitals, other population centres	≥ 30.5 m
Class A industrial buildings	≥ 12 m
Class B industrial buildings	≥ 10 m
Class C & D industrial buildings (fire rating I/II)	≥ 10 m
Industrial buildings (fire rating III)	≥ 12 m

Flood, geology and security: avoid low-lying or flood-prone areas - the site should be at least 1000 mm above the historical maximum water level or wave height near water bodies, with adequate drainage of the surrounding area. Avoid soils prone to settlement and keep the site away from corrosive or polluted areas (coastal > 2000 m; heavy pollution sources > 1500 m). Enclose the area with locked fences or walls and restrict access to authorised personnel.

5.1.3 Foundation Preparation

Foundation

The concrete foundation or channel-steel structure must withstand at least 3 Tons without deformation, be flat, solid and flame-retardant, with no depression or inclination, and comply with local regulations.

Cable trenches must be pre-built for bottom-in / bottom-out cable entry, and holes pre-drilled to match the cable holes in the cabinet base. The base has four positioning Ø18 holes with slotting length of 30 mm. For a concrete base, use grade C30 concrete with a bearing capacity above 150 kPa; compact backfill in layers to a compaction coefficient of at least 0.94.

Obtain detailed layout drawings from Freedom Won for each project for finalising the foundations to avoid discrepancies that may arise from product changes.

5.1.4 Space Requirements

Maintain adequate clearance for maintenance, escape and ventilation. For a single cabinet, allow at least 2500 mm in front and at least 850 mm behind (1050 mm is required to fully open the rear door; 850 mm is the minimum maintenance distance). For multiple cabinets, a matching Point-of-Connection (POC) cabinet supports up to 6 units in parallel; where more units are required, divide them into multiple systems each with its own POC cabinet. Final spacing must follow site conditions and local regulations. See below layout suggestions for various configurations.




Figure 5-1 Front and Rear Space Requirements for One Cabinet




Figure 5-2 Suggested Layout with Six Cabinets




Figure 5-3 Suggested Layout with Twelve Cabinets – Main Doors Facing Inwards




Figure 5-4 Suggested Layout with Twelve Cabinets – All Main Doors Facing Forwards




Figure 5-5 Suggested Layout with Twelve Cabinets – Main Doors Facing Outwards

5.1.5 Cable Preparation

Select cable cross-sections according to the maximum AC/DC-side current with margin, using the same specification and type on each side. Recommended connections are listed below (copper cores; adjust for aluminium or non-standard orders).

Table 5-2 Recommended Cable and Terminal Specifications

Symbol	Function Description	Bolt Spec.	Max. Voltage and Current	Cable Recommendation	Cable Terminal
A	A-phase input terminal	M10*20	Voltage≤460V Current≤199A	Flexible cable 70-95mm ²	DT70/95-10
B	B-phase input terminal	M10*20	Voltage≤460V Current≤199A	Flexible cable 70-95mm ²	DT70/95-10
C	C-phase input terminal	M10*20	Voltage≤460V Current≤199A	Flexible cable 70-95mm ²	DT70/95-10
N	Neutral input terminal	M10*20	Voltage≤460V Current≤199A	Flexible cable 70-95mm ²	DT70/95-10
PE*	Grounding interface	M8 or M12	/	PE cable 35-70mm ²	GTNR35/70-8

Lay power and communication cables in separate trenches; cross them at right angles and keep communication cables away from power cables (minimum parallel-run separation 200 mm, increasing with run lengths over 1m to a required gap of at least 500mm). Protect both cable types in trays, securing communication cables with ties where trays cannot be used, and protect power-cable insulation from damage. Tighten copper-lug bolts to the torques in Appendix A.

5.2 On-Site Installation

Before you start

Confirm that both the AC and DC sides are dead, do not touch live parts, and ensure all connections comply with local electrical standards. Only qualified electricians may perform electrical connections. Inspect every cable and replace any with insulation defects.

5.2.1 Removal of Packaging

At least two people are required. Remove the top plate, then the wooden sides and shielding material, then the anchors securing the cabinet to the transport pallet; the cabinet can then be lifted from the pallet. Once removed, never transport the cabinet on the pallet again, and handle it with care as it can tip. Retain the shielding materials and desiccant if the cabinet is to be repacked for storage.

5.2.2 Cabinet Foundation

Two methods are recommended (final design per local requirements).

Method 1 - channel steel: fix the cabinet to suitably sized channel steel with M16 bolts through the pre-drilled base slots:




Figure 5-6 Cabinet Mounted on Steel Channel

Method 2 - concrete base: grade C30 concrete, bearing capacity above 150 kPa, with compacted backfill.




Figure 5-7 Cabinet Mounted on Concrete Plinths




Figure 5-8 Method for Multiple Cabinets Mounted on Steel Channel - Frame Example

5.2.3 Accessories and Cable Connection

The internal wiring is completed at the factory. On site only the connections or installation actions described below are required:

1. Lifting ring installation
2. MSD installation and AC cable connection
3. Communication cable connection
4. External communication terminals and parallel communication plug connection
5. Grounding connection




Figure 5-9 On-Site Wiring and Installation Actions

Five safety rules. Before any electrical work: (1) disconnect all external and internal supplies; (2) prevent re-energisation (lock out); (3) verify the cabinet is dead with a multimeter; (4) apply earthing/short-circuiting as required; (5) cover nearby live parts with insulating covers.

Lifting rings. Install the four lifting rings (shipped inside the cabinet) at the top corners even if lifting is not needed, to preserve the protection rating.

MSD. Open the handle to 90° to the connection surface, insert the MSD horizontally, flip the handle up while pushing it fully home, then press the central button until it clicks.




Figure 5-10 MSD Installation

AC cable connection (not for the DC261). With the battery disconnected: strip the cable to the lug-barrel depth + 5 mm; fit heat-shrink and the DT lug; crimp the lug at least twice; shrink the sleeve over the lug; then bolt the lugs to the busbar in A-B-C-N order and tighten to 20 N·m. Confirm the connection is secure.

Communication / network. Connect the HVB COM2 port to the EMS/gateway. To set the network, connect COM2 to a computer (or common gateway); the cabinet default address is 172.23.1.201 - set the computer to the same subnet, log in to the local web (172.23.1.201:38080), set the cabinet IP, subnet mask 255.255.255.0, gateway and DNS, then restart the cabinet (off in the order QF4→QF3→QF2→QF1, wait 10 s, on in the order QF1→QF2→QF3→QF4) and reconnect COM2 to the gateway.




Figure 5-11 Communication Terminals on the HVB

External terminals (optional). Use COM1 to communicate with a POC cabinet (breaker status/trip and meter RS485). For off-grid parallel operation, connect the STS to the master unit's Para1 and chain Para2→Para1 between units. Connect an external UPS at the XT1 terminal by removing the factory links between pins 3 and 4 and wiring to the UPS L and N.




Figure 5-12 COM1 Plug for Connections to the STS or POC Cabinet

Table 5-3 Pinout for COM1 Plug

Pin No.	Definition	Pin No.	Definition
1	Breaker status DI signal	9	BMS debugging CANL
2	Breaker status COM signal	10	PCS debugging RS485A1
3	Breaker trip DO+ control	11	PCS debugging RS485B1
4	Breaker trip DO- control	12	RS485A2 (Reserved)
5	/	13	RS485B2 (Reserved)
6	On-site Meter Comm. RS485A	14	/
7	On-site Meter Comm. RS485B	15	/
8	BMS debugging CANH	16	/

For parallel communication between each cabinet and the STS the Para 1 and Para 2 ports are daisy chained as per Fig 5-13 (applies to AC261 only).




Figure 5-13 PARA Communications Ports

Grounding. The grounding plate provides M12 and M8 screws - use one. Fit a 35–70 mm² PE cable with a suitable DT lug, comply with local grounding codes, and confirm the grounding resistance does not exceed 4 Ω. A poor earth can cause fatal shock, equipment damage from lightning, or malfunction.




Figure 5-14 Grounding-Plate Connection

5.2.4 DC Connections Specific to the DC261

All internal wiring for the liquid-cooled energy storage system has been completed prior to dispatch, and the external PCS cable harness has been routed to the connection points. Users need only connect the external cables. The external interfaces include DC-side cable connection ports, an external auxiliary power supply interface and external communication ports. Details of the connection ports are shown in the figure below:

Table 5-4 DC cable connections

No.	Function Description	Recommended Cable	Terminal Specifications	Remarks
1	DC output cable	Single-core flexible copper cable 4x 35 mm ²	ES-BPC-C 35 OG/ES-BPC-C 35 BK	2-channel DC output, 2 wires each for positive and negative
2	AC auxiliary power supply	2 x 4 mm ² single-core sheathed cable	M8	1
3	External communication cables (RS485, CAN)	Cat 5e shielded ethernet cable	RJ45	3




Figure 5-15 Cabinet with Inverter

Table 5-5 Features Labelled on Figure above

No.	Function Description	Qty	Remarks
A	Sunshade Awning	1	Awning for hybrid inverter
B	Inverter Hanging Area	1	Mounting for inverter installation (Numerous inverter brands are supported)
C	Wiring Compartment Cover	1	Protective cover for inverter wiring

The positions and dimensions of the DC cable connectors are shown in the figure below:




Figure 5-16 Diagram of DC cable connections

The recommended terminal block models for DC cables are shown in the table below.

Table 5-6 DC cable connections

No.	Item	Description
1	DC cable connection	4 x 1×35mm ² copper-core power cables, 2 DC output circuits, each with 2 power sockets; ensure the locking mechanism is fully engaged until a ‘click’ is heard.
2	Connector Model	ES-BPC-C 35 OG/ES-BPC-C 35 BK

5.2.5 Sealing of Inlet Holes

After checking all connections, seal the cable gaps with the fireproof mud supplied with the cabinet. Do not remove the protective sponge that prevents cable insulation damage. Poor sealing risks moisture ingress and entry of rodents.

5.2.6 On-Grid Parallel Connection (SOLVA AC261)

For on-grid only parallel operation, each cabinet passes through its QF1 breaker before the junction and then through the main breaker (QF) to the grid. Each cabinet reports its QF1 status and trip signal through DO; the master additionally collects the QF trip signal and controls the breaker through DI. The UPS, SPD and meter are integrated in the POC cabinet, and the HVB COM2 port connects to the higher-level EMS/gateway for data upload.




Figure 5-17 On-Grid Parallel Connection

5.2.7 Off-Grid Application (SOLVA AC261)

Off-grid and on-grid operation with seamless transition from on grid to off grid requires a Freedom Won STS cabinet. For pure off grid applications an STS cabinet is not required, in which case a standard POC cabinet can be used. In such instances if a generator is used it must be set up in “following” mode and controlled by the microgrid controller.

5.2.8 Installation Checklist

- Cabinet undamaged and undeformed, with sufficient maintenance space and suitable temperature, humidity and ventilation;
- Clear warning signs posted, and no flammable, explosive or hazardous materials nearby;
- Grounding cables complete and secure; power cables correct and secure; communication cables correct and separated from power cables; cable IDs clear;
- Insulating covers and warning signs complete and secure; no tools, parts, waste or conductive dust inside; cabinet and cables neat and secure.

6. Power On and Off

Caution

Before powering on, confirm the emergency-stop button is not pressed. Commissioning and energisation must be performed by qualified technicians.

6.1 Power-On

1. With the mains connected, close the HVB switches QF1, QF2 and QF3 in sequence (the external PCS remains in shutdown after power-up - confirm its status on the HMI or web platform).
2. Close QF4; the BMS then closes the main contactors.
3. The cabinet RUN indicator lights, confirming the cabinet has powered on.

On power-up the BMS performs a self-check; if no faults are found the HVB operation indicator lights and the high-voltage contactor closes, producing DC voltage at the battery terminals. The Local EMS controller then checks the PCS; if no faults are found it commands the PCS to close its main contactors (otherwise the PCS stays in standby), after which the PCS performs its grid-connection self-check.

Danger

During commissioning or maintenance, if the PCS is not in standby, it is strictly forbidden to power on using the BMS.

6.2 Charging and Discharging

After power-on, the Local EMS controller runs its programmed operation and issues charge/discharge commands; the BMS monitors the current and the PCS performs charging or discharging. During charge/discharge both the green (RUN) and white (POWER) indicators are lit.

6.3 Power-Off

1. Open QF1(DC) on the HVB, then QF4 - the main contactors open and the green and red HVB indicators go out, indicating the high-voltage box is off.
2. Open QF3 to stop the chiller, then QF2 to disconnect the 220/230 V auxiliary supply, then the upstream power distribution board to disconnect from the grid.
3. The white indicator on the front panel goes out, confirming the cabinet is powered off.

Caution

Before powering off, ensure the cabinet has exited charge/discharge mode. Never cut the supply while the cabinet is charging or discharging.

7. Maintenance

7.1 Emergency Faults

7.1.1 Fire

Evacuate personnel to a safe place, establish an isolation zone and alert the relevant personnel. Where it is safe to do so: fight a cable/harness fire with a CO₂ or dry-powder extinguisher; fight a cabinet fire with a high-pressure water jet from a distance; and if smoke is inhaled, evacuate and seek medical attention at the nearest hospital. If the fire is caused by abnormal charging or discharging, cut the supply first, then extinguish. Inform Freedom Won as soon as possible.

7.1.2 Water Flooding

If the cabinet is flooded, whether or not the system is powered, evacuate personnel and establish a safe isolation zone. Notify Freedom Won immediately for decommissioning assistance, and do not attempt to restart the cabinet. A flooded battery may pose a fire risk after the water recedes.

7.2 System Maintenance

7.2.1 Maintenance Methods

To preserve battery health, periodically perform a full charge/discharge cycle. For a cabinet at low SOC: discharge to the cut-off condition (average cell voltage < 3.1 V or minimum < 2.8 V), rest 1 hour; charge to 100% SOC (max cell voltage > 3.65 V), rest 1 hour; then discharge to 40% SOC. For a cabinet at high SOC, perform the same steps starting with the charge.

7.2.2 Maintenance Intervals

Normal operation (daily use) and **intermittent operation**: carry out battery-system maintenance and a full inspection every 12 months and keep records. **Long-term idle** (shut down for more than 3 consecutive months): keep SOC at 30–50% (never below 15%), inspect and maintain every 3 months with records, and fully charge the cabinet at least once before returning it to service.

7.3 Component Maintenance

Maintenance intervals below are recommended values and may be adjusted to suit the site. Always observe local safety precautions and power off for at least one minute before cleaning or working on components.

Table 7-1 Maintenance Intervals

Component	Standard / check	Interval	Method
PCS dust filter	Free of dust, blockage and damage	6 months	Brush clean or replace the filter
Smoke / heat detector, alarm, aerosol	Appearance clean and intact	1 month	Visual; contact service if abnormal
Chiller operating data	Current, voltage and inlet/outlet temperature within range	1 month	Visual; contact service if abnormal
Chiller / cabinet filters	Free of dust, blockage and damage	1 month	Brush clean or rinse and dry
Cooling fan	Clean, unobstructed, no abnormal noise	6 months	Brush clean; tighten; replace if faulty
Cables and terminals	No looseness, ageing, damage or abnormal heating; no dust	6 months	Re-tighten or replace; clean
Coolant	Concentration within range	6 months	Visual; contact service if abnormal
Coolant replacement	Glycol-based, -35 °C, 45-55% concentration	5 years	Replace with a professional filling machine

Do not mix coolant brands. Replace coolant with a professional filling machine following the gas-tightness test and filling procedure; contact Freedom Won for the approved filling machine or to approve your own.

8. Warranty

The SOLVA 261 carries a standard 5-year warranty (extensions available). Warranty cover is subject to correct installation, operation and maintenance in accordance with this manual; the exclusions in Section 2.3 apply. Refer to your Freedom Won warranty certificate for the full terms and conditions.

9. Support and Contact

For project enquiries, technical guidance, spare parts or service, contact Freedom Won.

Company	Freedom Won (Pty) Ltd
Website	www.freedomwon.co.za
Product range	SOLVA 261 (AC261, DC261, RT261)

Disclaimer

The images featured in this manual are for illustrative purposes only. Although we have taken care to ensure all information is accurate at the time of publication, we cannot be held responsible for any errors, omissions, or changes that may occur. For the most up-to-date information, please contact us directly.

Appendix A - Tightening Torques

Tighten copper-terminal hardware to the values below to avoid loose connections, increased contact resistance and overheating.

Table A-1 Recommended Tightening Torques by Bolt Size


Bolt size	Torque (N·m)
M3	0.7 – 1
M4	1.8 – 2.4
M5	4 – 4.8
M6	7 – 8
M8	17 – 20
M10	34 – 40
M12	60 – 70
M16	119 – 140

The AC power-cable copper lugs are to be tightened to 20 N·m. Values apply to bolt-and-nut combinations and not to riveted fasteners.


Appendix B - Detailed Single-Line Diagrams

The following full-size single-line diagrams expand the system architecture overviews in Section 3.4. They show the internal protection, busbars, power conversion and auxiliary subsystems of each SOLVA 261 model for design reference. Final protection ratings and device selection must follow the project design and local regulations.

B.1 SOLVA AC261 - Detailed Single-Line Diagram



B.2 SOLVA DC261 - Detailed Single-Line Diagram



B.3 SOLVA RT261 - Detailed Single-Line Diagram

